


Table Assembly Instructions





Your table comes packaged in one box.

DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.

Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching the finish.



Parts List


- 1 1 x Table Top 
- 2 1 x Crossbar 
- 3 4 x Table legs 
- 4 4 x Adjustable Feet (pre-installed) 

Hardware List

- A 4 x Short Bolts  M6 x 10mm
- B 4 x Long Bolts  M6 x 20mm
- C 4 x Flat Washers  M6 x 16mm
- D 1 x Hex Key  M4 x 140mm


Assembly

Step 1




Step 2

Loosely attach bolts




Assembly

Step 3




Step 4

Loosely attach all bolts before fully tightening




Step 5

Fully tighten all bolts



Step 6

It is highly recommended to use coasters or mats beneath hot pans, plates and glassware to protect the surface and finish of the furniture.



Your table style may differ from images. Care for your furniture by periodically tightening all bolts using the included hex key.

One Year Warranty: The furniture is warranted against defects in workmanship and materials. Items covered would be seam slippage, frame structural integrity, fit and finish of parts. Items not covered would be product abused by the user, normal wear and tear, stains or discoloration due to use, damage in any transportation. Softening of foam is considered normal wear and tear and is not covered by warranty. Warranty is for PARTS ONLY and does not include transportation and labor costs associated with any warranty claim.

CAUTION: Tighten all components securely before use. Failure to do so may result in personal injury.

Customer Support: 866-238-0531
Mon-Fri 8:00am - 4:30pm CST
customerservice@furniturequestions.com