





- 1) Using scissors, cut the two (2) red zip ties that are holding the extension cables and the transformer to the rear floor rail. Be careful to NOT cut the cables.
- 2) Until wire tie from extension cable and extend cable behind furniture.
- + 3) Assemble all connections per the above diagram.
 - 4) BATTERIES ARE NOT INCLUDED. USE (2) QUALITY 9-YOLT BATTERIES. Battery back-up option will only operate during a power outage. Battery life will allow only a limited number of cycles. To ensure future emergency operation, replace the batteries each time the chair has been operated during a power outage.

CAUTION: Ensure that the transformer is located where the chair will not hit it while reclining.



