


ASSEMBLY INSTRUCTIONS.

CLAY ARMLESS CHAIR LIVESMART FABRIC LIGHT GREY

YJ-1001-29



THANK YOU FOR YOUR PURCHASE!


PARTS AND HARDWARE.

No.	Description	Image	Qty
A	Body		1
В	Wood Legs	®	4
С	U Clip		2



Thank you for purchasing this quality product! Be sure to check all packing material carefully for small part that may have come loose inside the carton during shipping.

COUTION: The item is heavy, assembly should be performed by two people.



STEP 2.

