

Assembly Instructions for Hammock Chair C-Stand



Caution: Must place on level stable surface. Make sure all nuts and bolts are tightened securely. Maximum weight capactiy is 300 lbs. Do not jump or bounce while using stand. Use for hanging hammocks, not as a swing. Follow all instructions, not doing so may cause serious injury.

G

1

E -

We stand behind our brand and the quality of the items we sell. We will send new parts, or replace products at our discretion within the one year warranty period. Before we can help, you will need to provide proof of purchase with the date of purchase and photos of the defective merchandise. We will use the photos to determine the cause of defect and for future quality control.

A

Can

В

С

D

F

=0