



MODEL: 32037
PACKING DIAGRAM





ASSEMBLY INSTRUCTIONS

READ AND SAVE THESE INSTRUCTIONS

READ INSTRUCTIONS ALL THE WAY THROUGH PRIOR TO ASSEMBLY.

MAKE SURE ALL PARTS ARE FIRMLY TIGHTENED.

UNPACK THE LAMP

YOU SHOULD HAVE RECEIVED THE FOLLOWING PARTS IN THE PACKAGE: LAMP BODY AND TRANSFORMER. TO PROTECT THE FINISH, PLACE ALL PARTS ON A SOFT SURFACE.

ASSEMBLE THE LAMP

1. INSERT CONNECTOR INTO THE INPUT JACK IN THE BASE.

2. PLUG THE TRANSFORMER INTO AN OUTLET AND TURN ON AT SWITCH, YOUR NEW LAMP IS READY FOR USE.

IMPORTANT NOTES:

- (1). PUT YOUR FINGER ON THE TOUCH DIMMER SWITCH, THE LED LIGHT WILL CHANGED FROM BRIGHT TO DARK.
- (2). PUT YOUR FINGER ON THE TOUCH DIMMER SWITCH AGAIN, THE LED LIGHT WILL CHANGED FROM DARK TO BRIGHT.
- (3). THE LED LIGHT HAVE MEMORY FUNCTION, IT CAN REMEMBER THE BRIGHTNESS THAT YOU TURN ON THE LED LIGHT LAST TIME.

TROUBLE SHOOTING

1. IF YOUR LAMP DOES NOT LIGHT, CHECK PLUG AT THE OUTLET. MAKE SURE THE PLUG IS FULLY AND PROPERLY INSERTED INTO THE POWER OUTLET.

2. IF THE LAMP STILL DOES NOT LIGHT, PLEASE CONTACT YOUR DISTRIBUTOR OR PLACE OF PURCHASE.