

Read this instruction carefully. See hardware and furniture part list for guidance.
Be sure all parts are complete before assembly. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched.
Follow the figure to start assembling.


CAUTION : 1. Do not FULLY - TIGHTEN the nuts or nut bolts until they are ready for assembly.
2. Do not OVER - TIGHTEN the nuts or bolts to avoid causing damages to the thread.
3. Keep all hardware parts out of reach of children.

PART LIST		
ITEM	DESCRIPTION	QTY
A	SEAT	1PC
B	LEG	2 PCS
C	LEG SUPPORT	1 PC

HARDWARE LIST		
ITEM	DESCRIPTION	QTY
1	JCBC BOLT M6 x 20mm	1 PC
2	JCBB BOLT M6 x 30mm	4 PCS
3	WOOD SCREW M4 x 38mm	4 PCS
4	M4 ALLEN KEY (BALL SHAPE)	1 PC

NOTE : THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.
Tools needed : Screwdriver (not provided).





STEP 1




ASSEMBLY INSTRUCTIONS

2 OF 4





STEP 2



Don't screw tight



STEP 3





ASSEMBLY INSTRUCTIONS

4 OF 4

STEP 4

INSTRUCTIONS FOR ADJUSTING LEVELER :
POSITION THE CHAIR IN YOUR SPACE AND LOCATE THE
LEVELER UNDER EACH LEG. TURN THE
LEVELER COUNTER-CLOCKWISE TO EXTEND THE
LEVELER AND CLOCKWISE TO RETRACT IT.



STEP 5

