Marley Round Dining Table

(MH-TB-828)



ASSEMBLY INSTRUCTIONS

Do not throw away the packaging material until the assembly is complete.

To protect finish, assemble this item on a soft surface such as a cardboard or a carpet.

Until all parts are in place, do not fully tighten all the bolts

CARE INSTRUCTIONS


Wipe only with a soft & dry cloth.

To protect finish, avoid the use of chemicals and household cleaners.

Any liquid spilled on the furniture should be cleaned up immediately with a damp cloth.

PRODUCT PARTS

HARDWARE PROVIDED




A TABLE TOP




B1

В2





4X




E FLAT WASHER M8x3mm 8X




STEP 1


Turn the Table Top (A) upside down and align the Table Legs (B1) on top of the holes in the Table Top as highlighted in red below.




Once aligned, begin to place the Washers (E) and Screws (C&D) on the legs. First place the Washers (E) and then add the Screws (C&D) on top.



STEP 2 Use Screw (D) on the narrow parts and Screw (C) on the broad parts of the Table Legs. For easier understanding, refer to the image below.




Using the L-Key, (F) tighten all Screws and Washers to secure the Table Legs (B1) in place.



STEP 3

Now, diagonally place the other set of Table Legs (B2) on top of the previously attached Table Legs (B1), as shown below. Place them as such that they fit with the other pair of legs.



Use Screw (D) on the narrow parts and Screw (C) on the broad parts of the Table Legs. For easier understanding, refer to the image below. Using the L-Key, (F) tighten all Screws and Washers to secure all the Table Legs (B2) in place.



