
ASSEMBLY INSTRUCTIONS



NOTE TO CUSTOMERS:

- For ease and speed of assembly we recommend that before you commence each step of the assembly that you identify all the parts required to complete that step.
- We recommend that where possible you allow sufficient space to assemble the item as close as possible to the place where it will be once assembled.
- For the protection of your furniture we recommend that the product is placed on protected surfaces during assembly to prevent any damage.
- During assembly do not over tighten the screws or bolts, as this may damage the product.
- Please ensure you retain all the product packaging until the item is completely assembled.
- Periodically check all fitting and re-tighten as necessary.
- Never allow any liquids to remain on your furniture as absorption can cause the wood to warp or finish to de-laminate.
- It is recommended that this item should be assembled by two adults.

ASSEMBLY INSTRUCTIONS

PARTS IDENTIFICATION Glass Table Top A-1 pc B-Long Apron 2 pcs C-**Short Apron** 2 pcs Leg (Left) D-2 pcs Leg (Right) E-2 pcs F-Decorative Wooden Block 8 pcs HARDWARE IDENTIFICATION Allen Key M4 1-1 pc JCBC Bolt M6 x 80mm 2-16 pcs 3-Spring Washer 1/4" 16 pcs Flat Washer 1/4" Ø 1/4" 4-16 pcs 5-Glass Support 4 pcs **Bolt for Glass Support** 4 pcs 6-

NOTE: Quantities shown are for one table. Bolts are metric screw threads

ASSEMBLY INSTRUCTIONS

