




Parts Breakdown




Replacement Parts

Item	Description	Part Number
A	Cap Assembly	RTS-DIVCAP-SRT
C	Cartridge Extender	RTS-DIVEXT-SRT
D F	Cartridge Retaining Sleeve	RTS-2DIV
B G H I	Spacer 1" Cap Extender 1" Cartridge Extender 4" Mounting Screws	RTS-DIV-1EXT

Tools Required

Adjustable Wrench	
Drill (optional)	
Plumber Tape	
Safety Glasses	
Solder	
Torch	



Important:
Cartridge (D)
must be installed
with arrow
facing down.