


PART LIST

No	Description	Qty
1	Back Rest	1Pc
2	Box Frame with Seat	1Pc
3	Stretcher (L & R)	2Pcs
4	Front Leg (L & R)	2Pcs
5	Front Stretcher	1Pc


ASSEMBLY INSTRUCTION

A 7007-24


STEP 1




STEP 2



STEP 3



STEP 4



ASSEMBLY TIPS :

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

IMPORTANT NOTE :

- * Place all wooden parts on a clean and smooth such as a rug or carpet to avoid the parts from being scratched.
- * If chair/stool wobbles place chair/stool on a known flat level surface loosen the bolts so that the chair sits level and retighten.
- * Before you begin, Kindly follow the assembly instructions step by step.

A		1Pc	Allen Key M4 (Short)
B		4Pcs	Jcbc Screw M6 x 80mm
C		4Pcs	Jcbc Screw M6 x 60mm
D		3Pcs	Jcbc Screw M6 x 35mm
E		11Pcs	Spring Washer 1/4"
F		11Pcs	Flat Washer 1/4"
G		6Pcs	Wood Screw M4 x 38mm

PAGE 2 OF 2