

INSTALLATION INSTRUCTION
Silo X10 LED Track Luminaires
H/L/J-2010

WAC LIGHTING
Responsible Lighting®

WARNING

IMPORTANT: NEVER attempt any work without shutting off the electricity.

- Read all instructions before installing.
- System is intended for installation by a qualified electrician in accordance with the National Electrical Code and local regulations.
- Go to the main fuse box, or circuit breaker. Place the main power switch in the "OFF" position and unscrew the fuse(s) or switch "OFF" the circuit breaker switch(es) that control the power to the fixture or room that you are working on.
- Place the wall switch in the "OFF" position.

AVERTISSEMENT


IMPORTANT : Coupez l'électricité avant TOUTE manipulation.

- Lisez toutes les instructions avant d'installer.
- Système est destiné à être installé par un électricien qualifié en conformité avec le code national de l'électricité et les règlements locaux.
- Accédez au panneau central de disjoncteurs ou de fusibles de votre demeure et placez l'interrupteur principal en position d'arrêt (« OFF »).
- Placez l'interrupteur mural en position d'arrêt (« OFF »).

Overview:

Fixtures are designed for use on WAC Lighting's track systems.

LED TRACK LUMINAIRE	TRACK SYSTEM
H-2010 Series	120V H Track
L-2010 Series	120V L Track
J-2010 Series	120V J or J2 Track



Note: All parts must be used as indicated in these instructions. Do not substitute any parts, leave parts out, or use any parts that are worn out or broken. Failure to follow this instruction could invalidate the ETL/CETL listing of this fixture.

waclighting.com
Phone (800) 526.2588
Fax (800) 526.2585

Headquarters/Eastern Distribution Center
44 Harbor Park Drive
Port Washington, NY 11050


Central Distribution Center
1600 Distribution Ct
Lithia Springs, GA 30122

Western Distribution Center
1750 Archibald Avenue
Ontario, CA 91760

Fixture installation for H/ L/ J Track: (Fig.1)

1. The track has a groove running its length to indicate polarity and the locking tab has an arrow indicating locking direction.
2. Insert adapter into track slot. The arrow should point away from the grooved side of the track.
3. Push up and rotate the adapter into the lock position.
4. Reverse procedure to remove. The fixture may be positioned anywhere along the track.

Fig.1




FIXTURE POSITIONING: (Fig.2)

Power on fixture, rotate the luminaire's body horizontally or vertically to aim it properly.

The fixture can rotate $\pm 90^\circ$ vertically and 350° horizontally.

Fig.2



INSTALLATION INSTRUCTION
Silo X10 LED Track Luminaires
H/L/J-2010

WAC LIGHTING
Responsible Lighting®

REPLACING TIR LENS :

1. Use a screw-driver or finger nail on inside lips to gently pull out the front cap of the fixture. **Fig.3**
2. Use a flat-tip screw-driver and gently pry in lens holder removal slot to remove lens holder. **Fig.4**
3. Replace the Lens with the desired one.
4. Align plastic tabs and reinstall lens holder on securely. Ensure silicone guide is in place. **Fig.5**
5. Reinstall front cap

Fig.3




Fig.4





Fig.5



waclighting.com
Phone (800) 526.2588
Fax (800) 526.2585

Headquarters/Eastern Distribution Center
44 Harbor Park Drive
Port Washington, NY 11050

Central Distribution Center
1600 Distribution Ct
Lithia Springs, GA 30122

Western Distribution Center
1750 Archibald Avenue
Ontario, CA 91760

INSTALLATION INSTRUCTION
Silo X10 LED Track Luminaires
H/L/J-2010

WAC LIGHTING
Responsible Lighting®

ACCESSORIES : (Fig.6)

1. Use a screw-driver or finger nail to gently remove the front cap of the fixture.
2. Install the accessory into the front cap. Note: accepts one lens or one glare control accessory. **Fig.7**
3. Reinstall the front cap onto the fixture. Note: front cap will protrude off front of fixture the thickness of the accessory base. **Fig.8**

Fig.6




Fig.7





Fig.8



waclighting.com
Phone (800) 526.2588
Fax (800) 526.2585

Headquarters/Eastern Distribution Center
44 Harbor Park Drive
Port Washington, NY 11050

Central Distribution Center
1600 Distribution Ct
Lithia Springs, GA 30122

Western Distribution Center
1750 Archibald Avenue
Ontario, CA 91760