








ASSEMBLY INSTRUCTION

Item#: 5070-80113 End Table

**** Please make sure you have all parts indicated below prior to assembly.**

NO.	HARDWARE LIST		Q'TY
A		ALLEN WRENCH	1
B		BOLT	4
C		LOCK WASHER	4
D		FLAT WASHER	4
E		LEVELER	4
F		ALLEN WRENCH	1
G		BOLT	4





Diagram 1




Diagram 3

Diagram 2

Assembly Steps:

1. Take out the drawer. (See diagram 1)
2. Place the end table top upside down on a soft surface to prevent from scratching the top.
3. Attach one leg(J) to the top (K) using 1 bolt (B), 1 lock washer (C), 1 flat washer (D), secure by turning with allen wrench (A) in a clockwise direction. (See diagram 2).
4. Attach the other three legs in the same way as step 2.
5. Place bottom shelf (I) on posts (J). Insert bolts (G) through feet (H) and shelf (I) to posts (J) by using allen wrench (F) in a clockwise direction. Insert levelers (E) to bolts (G) in a clockwise direction (See diagram 3).
6. Turn the end table upright.
7. Put drawer back gently.

Cleaning Instruction: Clean finished parts with a damp cloth using a mild dishwashing liquid and water solution. Polish the finish with soft cloth and an industry recognized furniture polish.