









ASSEMBLY INSTRUCTION


Accent chair

Parts#	Parts Name	Drawing	Qty
A	Front Feet		2
B	Back Feet		2
C	Allen wrench		1
D	Flat Washer		12
E	Bolt(size:40*8mm)		12
F	Spring washer		12
G	Chair		1

Step 1. Turn the chair upside down and lay on protective carpet ,Open the black fabric of the bottom,and take out the legs underneath the seat.



Step 2: Attach the leg (A&B) to seat frame by using flat washer (D) , spring washer (F), bolt (E). Then tighten the bolts with allen wrench (C).



Step 3: Close the black fabric of the bottom, Turn the chair over.

