







BT-827-1  
PARTS







ASSEMBLY INSTRUCTION

<p>(1)X1</p> 	<p>(2)X4</p> 	<p>①</p> 
<p>(3)X4</p> 	<p>(4)X1</p> 	



BT-827-2  
PARTS


ASSEMBLY INSTRUCTION

<p>(1)X1</p> 	<p>①</p> 
<p>(2)X4</p> 	
<p>(3)X4</p> 	
<p>(4)X1</p> 	
<p>②</p> 	

827-3  
PARTS

ASSEMBLY INSTRUCTION

(1)X1



(2)X4




(3)X4



(4)X1



①



②

