

# **ASSEMBLY INSTRUCTIONS**

Description: Frank Wood Frame Upholstered Dining Side Chair.

# Important safety instructions:

- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

# Pre-assembly:

- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

# **Parts List**

Item	Description		QTY
P1	Chair Body		1
P2	Left Back Leg		1
P3	Right Back Leg		1
P4	Front Legs		2

### **Hardware List**

Item	Description		QTY
H1	Flat Washers Ø5/16"	0	8
H2	Lock Washers Ø5/16"	9	8
Н3	Nuts Ø5/16"	<b>©</b>	8
H4	Wrench	<u></u>	1


## **DISCLAIMER:**

WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.


# **Assembly Procedures:**

Step 1: Assemble the chair on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach the Left Back Leg (P2), Right Back Leg (P3) to the Chair Body (P1) as shown below. Tighten all nuts.

Step 2: Attach the Front Legs (P4) to the Chair Body (P1) as shown below. Tighten all nuts.



Step 3: Turn the assembled Chair to an upright position. Assembly is completed. Repeat the assembling steps for the 2nd dining chair.



ADDITIONAL NOTE ABOUT SAFETY: NUTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO ENSURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase