
Attention Installer

- Read these instructions carefully before installation. Inspect sink for damages. Do not install if the sink is damaged.
- Ariel recommends that installation of undermount sinks be done by a professional installer.
- Sink edges may be sharp and can cause accidental injury to installer if not careful. Wear cut-resistant protective gloves during installation.
- 4. Templates are only provided as a guide. Place template on sink to ensure the template will give you the proper cutout for the sink. Ariel is not responsible for improper sink or countertop installation. Ariel is not liable for any damages to sink or countertop or personal injury during installation.
- 5. The instructions in this guide are for installation on a wood countertop. For installation on granite, marble or cultured stone countertops ask your fabricator for proper installation instructions. Remind your fabricator to install the sink in a way that it can be.

Materials and Tools Needed

- Plumber's Putty
- Sink
- Sink Mounting Clips
- Silicon Caulk
- Philips Head Screwdriver
 - Jigsaw or Keyhole Saw
- Pencil
- Sink Cut-Out Template



- MOUNTING BRACKET **FASTENER** INVERTED COUNTERTOP
- 1. Position the template (provided with your sink) front to rear so the sink will not interfere with the cabinet; secure with tape.
- 2. Trace the template and remove. Dry fit the sink to verify the measurements.
- 4. Following the countertop manufacturer's instructions, carefully cut the countertop on the inside of the traced line.
- 5. Locate and drill the mounting holes, following the countertop manufacturer's instructions. Holes should allow even spacing of mounting brackets around the sink.
- 6. With the countertop inverted (upside down), fasten the mounting brackets to the countertop loosely.



- VERIFY SINK IS CENTERED WITHIN THE COUNTERTOP OPENING BEFORE TIGHTENING FASTENERS.



- 1. Clean the bottom of the countertop and the top flange (or lip) of the sink with denatured alcohol.
- 2. Apply a narrow bead of silicone adhesive sealant evenly all around the top of the sink flanges.
- 3. Position and align the sink over the countertop opening. Press silicone onto countertop.
- 4. Tighten fasteners until mounting brackets are snug against sink. Check alignment of sink to the countertop opening.
- 5. Tighten down fasteners evenly. Be careful not to over-tighten.
- 6. Immediately remove excess sealant.

IMPORTANT: The enclosed cutout template will create a countertop opening with a minimal (1/8" or less) reveal. It is recommended that you discuss this with your installer and agree that this finished appearance is the desired effect. Schön is not responsible for improper sink or countertop installations.

Overmount Stainlesss Steel Kitchen Sink

Care and Maintenance

- Clean regularly with normal detergent and warm water.
- Always make a habit of drying your sink after use and buffing with a soft cloth.
 This will ensure that no build up of limescale or other mineral deposits can occur.
- Clean the sink once a week using a nonabrasive cleanser such as Comet and a clean soft sponge. Scrub in the same direction as the natural grain of the sink.
- Never let soap or other household cleaners to dry on the surface of the sink. Most products contain addatives which will affect the finish of the sink.

- Never use bleach solutions on the sink, as it is harmful to stainless steel. If left on the sink too long it can cause surface pitting.
- Never use a steel wool pad to clean your sink. Doing so may damage the sink's surface and cause discoloration.
- Minor scratching of the sink's surface is extremely difficult to avoid and is not something to be unduly concerned about. These marks are usually only superficial and can be removed with a proprietary stainless steel cleaner.
- Use of rinse grids will reduce exposure of the bottom of the sink to scratches.

LIMITED LIFETIME WARRANTY

This product has been manufactured and inspected to the highest possible quality standards.

Should you experience any defects in materials or workmanship within the warranty period, we will repair or replace the defective product, subject to the following conditions:

- Any claim made under this warranty must include a copy of a valid proof of purchase showing the date and place of purchase.
- Our obligation under this warranty is to the original purchaser only, and may not be transferred.
- Product replacement does not include shipping costs or labor installation costs.
- This warranty applies to residential installations only.

This warranty relates to defects in manufacture, materials or workmanship in a stainless steel kitchen sink supplied for installation into domestic premises in the United States. It does not extend to:

- Damage resulting from failure to maintain the product in accordance with the Care and Maintenance instructions in this manual.
- Normal wear and tear, scratches or accidental damage.
- Faults arising from improper use and/or installation.
- · Defects in accessories, strainers and rinse grids.

All incidental or consequential damages are specifically excluded. No additional warranties, express or implied are given, including but not limited to, any implied warranty of merchantability or fitness for a particular purpose.

Some states do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you.

NOTE: Accessories such as rinse grids, cutting boards, strainers are not covered by this warranty.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.