

CHANNING COLLECTION

Neo-Classical lines, a dash of Hollywood glamour, and a top note of Mod moxie.

Acrylic knobs and polished nickel or brushed brass detailing pop on luxe lacquer.

CARE INSTRUCTIONS

- Wipe spills immediately. Do not allow water to collect on the surface.
- Avoid contact with hot items.
- Clean using a soft, dry microfiber cloth.
- Never use cleaner with alcohol or solvents on metals as they may damage the surface and finish. If your metal shows signs of significant wear, consult with a professional.
- If scratches on the lacquer surface develop, Novus cleaners may be used to repair. We recommend Novus Level 1 or 2 for buffing out light scratches.
- Wood is a natural material and responds to changes in temperature and humidity. Extreme fluctuations can cause wood furniture to crack and lacquer and finishes to lift.
- For the Channing Desk, we recommend retightening allen bolts every three months to ensure stability.