

ASSEMBLY INSTRUCTIONS

Description: FRAZIER COUNTER _ BAR STOOL.

Important safety instructions:

- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

Parts List

Item	Description	QTY
P1	Top	1
P2	Legs	3
P3	Metal Base	1
P4	Center Support	1
P5	Metal Ring	1

Hardware List


Item	Description	QTY
H1	Bolts Ø1/4" x 3/4"L	5
H2	Lock Washers 1/4"	5
H3	Flat Washers 1/4"x16	5
H4	Allen Wrench	1
H5	Flat Washers Ø30	1
H6	Nut	1
H7	Screw 1/8"x 1"L	6
H8	Screw 1/8"x 1-5/8"L	3
H9	Screw Driver	Not Provide

DISCLAIMER:




WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.


Assembly Procedures:

Step 1: Assemble the chair on a flat and soft surface either on a carpet or cloth to prevent the finish from scratching. Attach Legs (P2) to Metal Base (P3) then attach Metal Ring (P5) to Legs (P2), as shown below:




Step 2: Assemble the Screw (H8) to Leg (P2) then assemble the Screw (H7) to Leg (P2) as shown below:

- (H7)x6 Screw 1/8"x 2"L 
 (H8)x3 Screw 1/8"x 1-5/8"L 
 (H9)x1 Screw Driver 




Step 3: Attach Center Support (P4) to Top (P1), as shown below:

- (H1)x4 Bolts Ø1/4" x 3/4"L 
 (H2)x4 Lock Washers 1/4" 
 (H3)x4 Flat Washers 1/4"x16 
 (H4)x1 Allen Wrench 



Step 4: Attach Leg Frame to Center Support (P4), and attach the Nut (H6) to Center Support (P4) as shown below:


- (H1)x1 Bolts Ø1/4" x 3/4"L 
 (H2)x1 Lock Washers 1/4" 
 (H3)x1 Flat Washers 1/4"x16 
 (H4)x1 Allen Wrench 
 (H5)x1 Flat Washers Ø30 
 (H6)x1 Nut 



Step 5:

1. Turn the assembled table to an upright position.
2. Assembly is complete.

*** Usage Warning:** The stool must be adjusted with 2 position with height instruction below for stable. If it is not stable, it could lead damaging the product.



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO ENSURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase