









ASSEMBLY INSTRUCTION


Accent chair

Parts#	Parts Name	Drawing	Qty
A	Seat		1
B	Wood front legs		2
C	Wood back legs		2
D	Bolt(size:50*8mm)		8
E	Washer		8
F	Allen wrench		1
G	Spring washer		8

Step 1. Turn the chair upside down and lay on protective carpet
Open the black fabric of the bottom, and take out the legs underneath the seat.



Step 2: Attach the chair legs to seat frame, insert the bolts (D) and spring washer(G) and washers (E). then tighten the bolts with allen wrench (F)



Step 3: Close the black fabric of the bottom, Turn the chair over

