



ASSEMBLY INSTRUCTION SHEET



SUNPAN
MODERN HOME

sunpan.com

Description : 8 DINING TABLE

Item No: MF-1161







Please visit our web-site www.sunpan.com for more great products .

For assembly questions please call 1-800-787-1019 (or +14167360094) outside North America

or email to info@sunpan.com

PARTS LIST

Before you begin, please layout all parts and ensure you have the correct count

No	DESCRIPTION	Qty	ILLUSTRATION
A	Cabinet body	1	
B	Cabinet Leg	1	
C	Bolt (Head cap) (M8*25MM)	8	
D	Spring Pad ø13*2	8	
E	Gasket ø17*1.5	8	
F	Allen Wrench (5MM)	1	

ASSEMBLY INSTRUCTIONS

STEP	DESCRIPTION	ILLUSTRATION
1	Attach Leg(B) to Cabinet body(A) by using Bolt (Head cap) (C), Allen Wrench (D) to fix.	
2	Complete assembly	

ASSEMBLY TIPS:

- please check parts and hardware before assembling. Follow each instruction step by step.
- place a protective pad or piece of cardboard on the floor while assembling your item on top of it.
- remove all parts from the carton and separate them into part numbers/groups as indicated on the part list.
- please follow instructions in the sequence as numbered to assure fast/easy assembly

WARNING:

- don't attempt to repair or modify parts that are broken or defective - if you find a broken part please contact the retailer where you purchased it for replacement
- keep all hardware parts out of the reach of children

FURNITURE CARE:

Following these few basic steps will help to ensure that you enjoy your furniture for a long time:

- do not expose your furniture to direct sunlight, dampness or any heat, like a hot cup of coffee or tea. Always use a coaster.
- excessive exposure to sunlight may cause fading
- excessive temperature and humidity or cold may cause cracking or splitting
- dust with a clean, damp, lint free cloth
- use a damp cloth with water or mild detergent to clean all surfaces - do not use chemicals or paint thinner which will fade the surface
- place a piece of felt or a pad under the legs of your furniture to avoid scratching the floor