








Classic, Rope, Egg & Dart, Meadows, New York and Victorian Installation Instructions

Single Cylinder Deadbolt

*NOTE: Deadbolts fit doors 1-3/4" to 2-1/4" thick.
For thicker doors, please call customer service.*



NOSTALGIC
WAREHOUSE™


For
Assistance
Call:

1-800-522-7336

8 am - 5 pm, Monday - Friday, MST

NOTE: Deadbolts fit doors 1-3/4" to 2-1/4" thick.
For thicker doors, please call customer service.

Single Cylinder Deadbolt Exploded Parts Drawing



Part #	Part Description
1	Latch
2	Latch Faceplate
3	Latch & Strike Wood Screws (4)
4	Cylinder Body
4A	Tailpiece
5A	Spin Ring (N/A Classic & Rope)
5B	Outside Escutcheon
6	Deadbolt Adapter Plate
7	2" Machine Screws (2)
8	Thumbturn Assembly
9	5/8" Thumbturn Machine Screws (2)
10	Dust Box
11	Door Frame Reinforcer
12	3" Reinforcer Wood Screws (2)
13	Strike Plate

NOSTALGIC
WAREHOUSE

For Assistance Call: **1-800-522-7336**
8 am - 5 pm, Monday - Friday, MST