

ASSEMBLY INSTRUCTION

Item#:5072-50001 ACCENT TABLE

** Please make sure you have all parts indicated below prior to assembly.

| NO. | HARDWARE LIST | | Q'TY |
|-----|---|-------------------|------|
| A |  | 73MM ALLEN WRENCH | 1 |
| B |  | 5/16" BOLT | 4 |
| C |  | 5/16" FLAT WASHER | 4 |
| D |  | 69MM ALLEN WRENCH | 1 |
| E |  | 1/4" BOLT | 4 |
| F |  | 1/4" LOCK WASHER | 4 |
| G |  | 1/4" FLAT WASHER | 4 |
| H |  | 5/16" LOCK WASHER | 4 |




DIAGRAM2

DIAGRAM 1

Assembly Steps:

1. Place table top upside down on a soft surface to prevent from scratching.
2. Place four legs to table top using bolts (B), lock washers (H) and flat washers (C). (See diagram 1)
3. Insert bottom shelf to the legs then tighten all bolts securely with allen wrench(A).(See diagram 1)
4. Secure bottom shelf to legs using bolts (E), lock washers (F), flat washers (G) and turn bolts with allen wrench (D) in a clockwise direction.(See diagram 2)
- 5 Turn the table upright.

Cleaning Instruction: Clean finished parts with a damp cloth using a mild dishwashing liquid and water solution. Polish the finish with soft cloth and an industry recognized furniture polish.