
## CARE AND MAINTENANCE

Always use felt pads under all articles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from scratches and spills. How often you apply the wax depends on how much wear the furniture receives.

## NOTICE

- \* Please make sure that you have all parts indicated before you begin assembly of this item
- \* This item should be assembled on a soft surface to prevent scratching the finish during assembly
- \* This item may require periodic tightening

## **Part List and Hardware List**




Ax8	Bx8	Cx8	Dx4	Ex5	Fx13
			(g)		
				3. 5x40mm	6x12mm
Gx4	Hx4	lx2	Jx1	Kx1	Lx8
6x25mm	6x32mm	6x50mm	M5		



## Model# FOX2232A

Product Dimensions: (T)47.2"W×21.65"D×29.92"H (C)20.27"W×15.75"D×34.84"H





Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 40 minutes.







2



3

