Warm Shaker / Norfolk / Lexington

Bedside Table

Model # AXWSH-BS-RUS



brooklyn + max





It's time to register your product warranty.

It's quick and easy. And you'll be happy you did.



- ✓ Activate your 1-year warranty
- ✓ Automatic entry to win a \$500 gift certificate
- ✓ Earn instant rewards and save



simpli-home.com/product-registration

Review your product and collect rewards!

Thank you for your purchase! We hope you enjoy it. We'd love your feedback. Please share a review and get instant rewards!












Share photos and get your cash back!



Send us images or share them on social and qualify for instant rewards. You may even receive store credit on your entire purchase!





simpli-home.com/share-images

For Fastest Customer Service:



- 1. Open your phone's camera.
- 2. Point your phone's camera at the QR code to scan.
- 3. Click on the pop up.
- 4. You'll be taken to our customer service page.
- 5. Fill the form with your order information and issue.
- 6. Submit form.
- 7. A customer service associate will contact you.

Other ways to contact us...



Email Us

customer service@simpli-home.com



Visit Us

Visit our site directly at www.simpli-home.com



Call Us

1-866-518-0120 Monday to Friday 9am to 5pm EST

*If you've purchased from a retailer and you wish to return the product, please contact the retailer directly.

IMPORTANT: Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

Safety Information

Identify all the parts and hardware. Do not discard of the packaging until you have checked that you have all of the parts and hardware required. Hardware package may have spare parts.

WARNING: This item contains small parts which can be swallowed by children and pets. Keep children and pets away during assembly. To avoid danger of suffocation, always keep plastic bags away from children and pets. We recommend that you assemble this unit on a carpeted floor to avoid scratches. If using power tools, set the tool to low torque to avoid damage.

May require 2 people for ease of assembly.

Care & Maintenance

This furniture is designed for indoor use.

Perhaps the greatest environmental damage to wood furniture comes from wide swings in relative humidity (RH) in our homes. Wood absorbs and desorbs water as relative humidity rises and falls, and in doing so it swells and shrinks. Making matters worse, it expands and contracts unequally along different grain directions. As humidity changes, the components of wooden objects are continually pushing and pulling against each other. This pressure often results in parts of furniture no longer fitting together closely or becoming distorted or breaking from their own internal stresses.

The response to relative humidity changes begins with determining the annual average RH for your particular space. Then try to keep the RH in the space where your furniture is as close to that average as possible, generally within about 10% up or down. De-humidify in the summer and humidify in the winter.

Be aware that raising the temperature lowers the humidity and vice versa. Thus, modern heating systems, which can drive down interior RH in the winter, almost invariably cause problems for furniture. To counteract their effect, you can either modify the RH by keeping furniture containing spaces cooler in the winter or most importantly, have a good working humidifier for your home. A humidistat automatically works to balance the humidity in your home so it is constant. Dry indoor air can suck enough moisture from its surroundings to do permanent damage to wood, causing it to crack or split.

Remember, that not all woods are created equal. Two factors that help determine how rapidly a wood will lose moisture are pore size and surface hardness. A piece made from a dense and hard wood will dry less rapidly than pieces made from softer woods.

Furniture that is sealed and lacquered will lose moisture more slowly than an unfinished piece while pieces with veneer finishes are not only stronger but lose moisture more slowly than other finishes.

To help protect your wood furniture, take these steps:

- Use a humidifier, preferably one with an automatic control system that can sense the humidity level and adjust itself accordingly
- Don't over-humidify; that can damage wood by causing it to expand and contract
- Keep furniture out of direct sunlight, which can cause it to dry out, crack and warp
- If you can avoid it, don't put furniture near heating vents; if you can't, keep the item 3 to 4 inches away from the wall, giving the heat and air space to circulate
- Dust with soft dry cloth
- Do not use liquid or aerosol products
- To avoid marking, do not place rubber on surface (foot pads, etc.)
- For soil build-up, wipe with damp cloth & dry
- Do not use abrasive cleaners


Model # AXWSH-BS-RUS **Pre-Assembly Information Part Description** BL BR TOP **LEFT SIDE RIGHT SIDE** QTY 1 QTY 1 QTY 1 **BOTTOM SHELF** MIDDLE FRAME TOP BACK PANEL QTY 1 QTY 1 QTY 1 HL **BOTTOM BACK PANEL** LEFT DRAWER SIDE **DRAWER FRONT** QTY 2 QTY 1 QTY 2 HR RIGHT DRAWER SIDE DRAWER BACK DRAWER BOTTOM QTY 2 QTY 2 QTY 2

Pre-Assembly Information

Model # AXWSH-BS-RUS

Hardware Description


1



ALLEN KEY SCREW M6 X 30mm QTY 24 2



CAM LOCK PIN CAM LOCK QTY 8 SETS 3



WOOD DOWEL Ø8 X 30mm QTY 8


4




ALLEN KEY QTY 1 5



PHILLIPS SCREW ROUND HEAD M4 X 15mm QTY 16 6



HANDLE M4 X 25 mm QTY 2 SETS




Required -Flathead screwdriver Phillips screwdriver Rubber mallet

Not Included




Model # AXWSH-BS-RUS




Assembly


Model # AXWSH-BS-RUS



- 1. Attach four Cam Lock Pins 2 to pre-drilled holes at back of Drawer Front G.
- 2. Use Phillips screwdriver to secure Cam Lock Pins.




- 1. Align Cam Lock Pins with drilled holes and attach Drawer Sides (HL), (HR).
- 2. Insert two Cam Locks (2) into drilled holes on each Drawer Side (HL), (HR).
- 3. Use Phillips screwdriver to secure Cam Locks.




1. Slide Drawer Bottom J firmly into slots on Drawer Sides (HL), (HR) and Drawer Front (G).

Step 4




- 1. Align Drawer Back (I) with Drawer Bottom (J) and press firmly into slot .
- 2. Attach Drawer Back using two Allen Key Screws 1 through drilled holes on each Drawer Side (HL), (HR).
- 3. Use Allen Key 4 to tighten Screws. Do not over-tighten




1. Use Phillips screwdriver to attach Handle 6 to Drawer Front 6.


Repeat Step-1 to Step-5 for the second Drawer.




- 1. Insert four Wood Dowels (3) into drilled holes on Middle Frame (D).
- 2. Use rubber mallet to tap Dowels (3) into bottom of holes securely. 1/3 length of Dowels should be exposed.



- 1. Insert two Wood Dowels (3) into drilled holes on each Side (BL), (BR).
- 2. Use rubber mallet to tap Dowels (3) into bottom of holes securely. 1/3 length of Dowels should be exposed.




- 1. Attach Bottom Shelf C to Left Side (BL) using three Allen Key Screws 1.
- 2. Use Allen Key 4 to tighten Screws. Do not over-tighten.



2. Use Allen Key 4 to tighten Screws. Do not over-tighten.


Step 10




- 1. Attach Middle Frame (D) and Bottom Shelf (C) to Sides (BR) using five Allen Key Screws (1) (two Screws / Middle Frame, three Screws / Bottom Shelf).
- 3. Use Allen Key (4) to tighten Screws. Do not over-tighten.

Assembly

Model # AXWSH-BS-RUS




- 1. Attach Top (A) to Sides (B), (BR) using six Allen Key Screws (1) (three Screws / each Side).
- 3. Use Allen Key 4 to tighten Screws. Do not over-tighten.



Note:


The back of the table frame does not have pre-drilled holes to attach the back panels.



- 1. Attach Back Panels (E), (F) to back frame of storage using sixteen Phillips Screws Round Head (5) through drilled holes.
- 2. Use Phillips Screwdriver to tighten Screws.

Assembly

Model # AXWSH-BS-RUS



1. Insert assembled Drawers into glides on assembled Bedside.