User's Manual



INSTALLATION INSTRUCTIONS

Installation Manual





BEFORE INSTALLATION

Notes before installation

1. Confirm whether the inlet pipe and corner valve have been properly installed before installation.

2. Before installation, be sure to clean the dust, sand and other foreign bodies in the water supply pipe to ensure that the inlet pipe is free of sundries, so as not to shadow sound water outlet function.

3. Inlet water pressure of 0.05 Mpa \leq inlet water pressure ≤ 0.75 Mpa, if the water pressure is lower than 0.05 Mpa, it may cause poor effect for the water outlet.

4. The cold and hot water piping should not be mismatched, and the heating pipes should not use steam.

Recommend Tools And Materials



Level

Impact Drill



Adjustable Wrench

Installation Dimension



INSTALLATION STEPS

This product has been inspected and debugged by the factory to the best condition. Please do not disassemble and assemble it yourself.



Before installing the faucet, please be sure to remove sundries and sludge from the water pipe to prevent sundries from blocking the faucet.



1

1. Fix the embedded box with bolts according to the stabila level. Then connect the cold and hot water inlet pipes as shown in the figure. Open the water inlet valve to test whether the connection parts are leaking or not.



2 2. Fill the gaps between the water inlet pipe and the components in the wall with cement. Noted that the size of the hoses on the tiles are as shown in the size drawing. The surface of the tile should be on the same level as the label on the rough-in valve. Finally, take out the POM connector to expose both sides of the connection part of the valve.



3

3. Connect the handles with the thread of the main body. Pay attention to adjusting the direction of the handle during the tightening process. After adjustment, the cover plate should be tightly attached to the wall. (The horizontal position of the handle is the valve closed state)



INSTALLATION STEPS

4

4. Take out the protective cover in the middle of the main body. Then wrap thread of the spout and the faucet with PTFE tape and tighten it on the wall. Keep the spout downward. If it is not downward, you can loosen the top wire below, and then adjust it. Tighten it again and be careful not to leak water at the PTFE tape.

CLEANING CARE

In order to keep the appearance of faucet clean, bright and good performance, please take care of the faucet as follows;

1.Rinse with water only and dry with soff cotton cloth;



 $\langle \langle \mathcal{A} \rangle \rangle$

2.Use mild liquid and colorless glass cleaner to remove surface dirt and scale film, or use polish without abrasive effect;

3.Do not use abrasive deterfgent, polish, emery cloth, paper towel or scraper, etc.;

4.Do not use acid cleaner, or cleaner and soap with insoluble gran etc.;

5.In the process of use, mud my accumulate in the bubbler and make the water flow show, The bubbler can be unscrewed, rinsed with water, and then installed back in place.

