### **WARNING**

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN. WARNING \*\*\* SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL. ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

#### **CARE AND MAINTENANCE**

To clean the outside of the fixture, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the surface of the fixture.

To clean the inside of the fixture, first disconnect power to the fixture by turning off the circuit breaker or by removing the fuse at the fuse box. Next, use a dry or slighly damperned clean cloth (use clean water, never a solvent) to wipe the interior surface of the fixture.

Do not use any cleaners with chemical, solvents or harsh abrasives. Use only a dry soft cloth to dust or wipe carefully.

#### NOTICE& IMPORTANT SAFETY INSTRUCTIONS

- \* Please make sure that you have all parts indicated before you begin assembly of this item
- \* This item should be assembled on a soft surface to prevent scratching the finish during assembly
- \* To reduce the risk of fire, electrical shock or injury to persons or property, please follow the guideline below for safe use and installation
- \*The external flexible cable or cord of this luminaire cannot be replaced If the cord is damaged, the luminaire shall be destroyed


## **Part List and Hardware List**

PIECE	DESCRIPTION	PICTURE	QUANTITY	PIECE	DESCRIPTION	PICTURE	QUANTITY
А	Mounting Plate		1X	I	Cover		1 X
В	Wire Connector	₩	3X	J	Tube		1 X
С	Mounting Screw	Î	2X	К	Threaded Tube	пришения	1X
D	Canopy		1 X	L	Lamp Boby	BSX XSQ	1X
E	Canopy Nut	0	2X	М	Bulb		3X
F	Hex nut	<b>B</b>	1 X	N	Diffisuer	<b>S.</b>	1X
G	Spring washer	•	1 X	0	Finial		1X
Н	Flat washer	•	1X				



Model#: JYL9071A

Product Dimensions: Ø13.25"\*H10.25"



Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product. Estimated Assembly Time: 30 minutes.


1.Insert the fixture wires through the Threaded Tube(K), Tube(J), Cover(I) and Canopy(D).

2.Insert the Threaded Tube(K) into the nipple of the Lamp Body(L).Low down the Tube(J) around the Threaded Tube(K), place the Cover(I) over the Tube(J),the Canopy(D) onto the Cover(I).Fix it in place by placing Flat Washer(H),Spring Washer(G) and Hux Nut(F), then turn the Hux Nut(F) clockwise till tight.

3. Separate the Mounting Plate(A) from the Canopy(D) by removing the Canopy Nut(E) anti-clockwise.

4. Attach the Mounting Plate (A) onto the J-box and secure it by turning 2 Mounting Screws (C) clockwise till tight.

Connect, Hot, Black or Red Outlet Supply Wire to:	Connect, Neutral, White Outlet Supply Wire to:		
Black	White		
* Parallel Cord (round & smooth)	* Parallel Cord (square & ridged)		
Clear, Brown, Gold or Black without Tracer (colored stripes)	Clear, Brown, Gold or Black with Tracer (colored stripes)		
Insulated Wire (not green) with copper metal conductor	Insulated Wire (not green) with Silver metal conductor.		



\*Note: When parallel wire (SPTI & SPTII) is used. The neutral wire is square shaped and ridged and the hot wire will be round in shape and smooth. (See Illustration on left.)

# **Grounding Instructions:**

- a) For installation in the United States: Wrap ground wire from outlet box around green ground screw on mounting bracket, no less than 2" from wire end. Tighten ground screw. If fixture is supplied with a ground wire, connect to outlet ground wire with a wire connector.
- b) For installation in Canada: If fixture is supplied with ground wire, wrap ground wire around green grounding screw on mounting bracket. Tighten ground screw.
- 5.Attach the Canopy (D) to the Mounting Plate (A) and fix it by turning the Canopy Nut (E) clockwise.
- 6. Insert the bulb (M) into the Socket. Be sure to use light bulb(M) with wattage no greater than specified on this fixture. Make sure that electrical current is turned off before changing bulbs.

PLEASUE USE TYPE"B" BULB MAX 40-WATT OR CFL BULB MAX 13-WATT OR LED MAX 9-WATT THERE ARE 3 X 4W LED BULBS IN THE BOX.

7.Insert the Diffisuer(N) into the bottom frame, fix it with Final(O) clockwise till tight.

