
# **Assembly Instructions**

Caution: You must read this before you proceed

### Loveseat




Parts	List
	-


Label	Picture	Description	QTY
А		Left Armrest (with Legs)	1
В		Right Armrest (with Legs)	1
С		Backrest (with Legs)	2
D		Seat Panel	2
E		Front Panel (with Legs)	2

F		Left Front Foot Clip	1	
G		Right Front Foot Clip	1	
Н		Left Back Foot Clip	1	
I		Right Back Foot Clip	1	
J		Front Middle Foot Clip	1	
К		Back Middle Foot Clip	1	
L		Inner Panel (with Legs)	1	
М	110	Seat Cushion	2	
Assembly Preparation				
Before Beginning				
Assembly:				
Read instructions, cover to cover-  † 2- † • Have 2 adults on hand for assembly-  • Do not assemble on flooring or carpet-  • Assemble on a clean non-marring surface (packing foam)-  • Save all packaging until finished-				


## Assembly Steps




This Loveseat has multiple parts and may require up to 60 minutes to assemble. To give you an overview of the Loveseat parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.




Open the carton and place all parts on a clean, non-marring surface.
Place the two Front Panels(E) facedown on the clean, non-marring surface.
Insert the Clasps of the Front Panel(E) into the large part of Pear-shaped Clasp mounting positions of the other Front Panel(E) as shown above.
Button up the Clasps with the Rubber Hammer(Q) as pictured.




Align Inner Panel(L) to Middle Panel(E) as pictured above.
Insert the Dowel of the Inner Panel into the mounting position of the Middle Panel until it clicks into place.




Place the Seat Panels(D) facedown on the clean, non-marring surface.
Insert the Clasps of the Seat Panel(D) into the large part of Pear-shaped Clasp mounting positions of the other Seat Panel(D) and push down to button up the Clasps with the Rubber Hammer(Q).




With help from an adult partner, insert Front Panels(E) and Inner Panels(L) into Seat Panels(D) using the interlocking joints with Rubber Hammer(Q).




Place the Backrests(C) on the clean, non-marring surface.
Insert the Clasps of the Backrest(C) into the large part of the Pear-shaped Clasp mounting positions on the other Backrest(C).
Button up the Clasps with the Rubber Hammer(Q) as pictured.




With help from an adult partner, place the Backrests(C) on the Seat Panels(D) and Inner Panels(L) as shown above. Insert the Clasps of the Seat Panels(D) and Inner Panels(L) into the large part of Pear-shaped Clasp Mounting Positions of the Backrests(C).




With the help of your adult partner, stand the assembly upright. Button up the Clasps with the Rubber Hammer(Q) left to right as pictured.



Align the Left Armrest(A) to the left side of Backrest(C), Seat Panel(D), and Front Panel(E).
Insert the Clasps on the Left Armrest(A) into the Pear-shaped Clasp mounting positions on the Front Panel(E), Seat Panel(D), and Backrest(C).
Insert the 8 Clasps of Front Panel(E), Seat Panel(D), and Backrest(C) into Pear-Shaped Clasp mounting positions of Left Armrest(A).
Button up the Clasps with the Rubber Hammer(Q) from left to right as shown above.




Repeat the process from Step 8, to assemble the Right Armrest(B)




Attach the Left Front Foot Clip(F), Right Front Foot Clip(G), Left Back Foot Clip(H), Right Back Foot Clip(I), Front Middle Foot Clips(J), and Back Middle Foot Clips(K) to the feet of the 3 Seater using the Rubber Hammer(Q) as shown above.





With the help of your adult partner, stand the 3 Seater up on a Lever surface, to check for wobbles. If there are wobbles, use the Rubber Hammer(Q) to ensure all parts are properly secured.





Place the Cushion(M) on the seat. Your 3 Seater is ready for use. This 3 Seater can only be used on a flat, level surface.

# Care & Maintenance

Do not put hot items directly on furniture surface

Do not clean furniture with harsh cleansers or polish.

To obtain the longest lifespan of your outdoor prodcts, minimizing exposure to direct sunlight is recommended.

Children should not climb or jump on the furniture.

Do not write on furniture without a padded barrier to protect the surface. To obtain the longest lifespan of your outdoor products, avoid extended and

lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.

Not for commercial use For residential use only

Stains may be removed with mild soap solution and damp cloth.

Keep away from sources of ignition.

Dust and pick-up spills using a clean, non-colored, lint-free cloth.

#### What is Proposition 65?

Proposition 65 is a California law that requires warning labels on products that may contain one of more than 800-plus chemicals or ingredients that the California Office of Environmental Health Hazard Assessment (OEHHA) has deemed to cause cancer or other reproductive toxicity. Chemicals and elements on this list include wood dust, brass, and other everyday substances, which can be found in very common household items, such as: lamps, tableware, jewelry, crystal glasses, electric cords, beauty products, automobiles, and furniture.

#### Why Did I Find a Proposition 65 Warning on My Home Goods Product?

We include Proposition 65 warnings on all of our products because there is always a chance that one of the 800-plus common chemicals and ingredients listed under this law could potentially be on our furniture or packing materials. We risk large fines under

#### this law, if we don't include this warning. Should I worry?

We realize you may be worried finding this warning on our products, but we want to reassure you that the hazardous exposure limits for any of these chemicals have never been found on furniture products that we've shipped to our customers. Additionally, this warning label is very common and can be found on almost every piece of furniture sold in the state of California

#### Just How Common Are Proposition 65 Warnings?

Proposition 65 warnings have become so common in California that it is hard to take a trip to a local bank, grocery store, or restaurant without finding at least one warning. In fact, even the Disney Land Resort has a Proposition 65 warning:

