



Note:Do not use power tools for assembly.Power tools increase the risk of over tightening which lead to spliting or cracking the wood

Component list


NO	DRAWING	QTY	DESCRIPTION
А		4	Plastic legs 4" * 4-3/4"
В	8	5	Gaskets 1-7/10″
С		1	Center support plastic leg 2-1/4"*4-1/2"

step #1





step #3



Care Instruction for Fabric Furniture:

In order to maintain the original appearance of your fabric Furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and or exposure to heating and air conditioning outlets will fade/damage Fabric.
- Vacuum or wipe with a soft cloth to remove dust.



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration. Page 2 of 2