

## ASSEMBLY INSTRUCTIONS

### **Description:** Irisa Accent Table

#### Important safety instructions:

- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

#### Pre-assembly:

- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

#### Parts List

| Item | Description |            | QTY |
|------|-------------|------------|-----|
| P1   | Table Top   | $\bigcirc$ | 1   |
| P2   | Metal Base  | $\bigcirc$ | 1   |
| P3   | Metal Legs  |            | 4   |

#### Hardware List


| Item | Description         |   | QTY |
|------|---------------------|---|-----|
| H1   | Bolt Ø1/4" x 5/8"   | 0 | 4   |
| H2   | Bolt Ø1/4" x 1 1/4" |   | 4   |
| H3   | Lock Washers Ø1/4"  | Ø | 8   |
| H4   | FlatWashers Ø1/4"   | 0 | 8   |
| H5   | Alen Wrench         | Ľ | 1   |


#### DISCLAIMER:

# WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.

#### **Assembly Procedures:**

Step 1: Assemble the table on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach Metal Legs (P3) to Table Top (P1) as shown below:






Step 3:

a. Securely tighten all bolts with Allen wrench (H5), turn the assembled table to an upright position.

b. Assembly is complete.

c.Failure to follow these instructions may cause the bolts to misalign during assembly.



Thank you for your purchase