

ASSEMBLY INSTRUCTIONS


30INCH BATH VANITY (COMBO)





Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.


Compare with the parts list to be sure all parts are present.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"


- 
- * Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe !!!
 - * Please assemble on a clean soft surface to avoid damage.




+



Tools Required



(Not included)



(Not included)

IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

PLEASE DO NOT RETURN TO STORE



**Please do not return this product to the retailer!!
We are able to assist you in ANY way**

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.

Before Installation

Important – Please read these instructions fully before starting assembly


Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

Cam Lock Assembly Instructions















	<p>Diagram A</p>	<p>Insert Cam Bolt into hole as shown in diagram A.</p>
	<p>Diagram B</p>	<p>Make sure not to insert the Cam Bolt: Too deep as shown in figure B as this will cause the Cam Lock to be misaligned and unable to interlock properly.</p>
	<p>Diagram C</p>	<p>Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C, as this will cause the Cam Lock to be too loose, and not interlock properly.</p>
<p>Connect the panels together.</p>		
<p>ARROW SIGN</p> <p>Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.</p>		
<p>To tighten the Cam Lock, turn it clockwise on half a turn with a flat screwdriver. <i>*Do not use an automatic screwdriver as it may bend or break if too much power is imposed.</i></p>		

Detail View - CABINET















Identifying the Hardware-Identify the hardware using the illustrations below.


Part List - N729P173380

1		2	
	Top Frame - 1pc		Top Side Panel - 2pcs
3		4	
	Mid Panel Rear - 1pc		Mid Frame - 1pc
5		6	
	Drawer Fake - 1pc		Panel Rear - 2pcs
7		8	
	Bottom Side Panel (L) - 1pc		Bottom Side Panel (R) - 1pc
9		10	
	Adjustable Shelf - 1pc		Cabinet Door (L) - 1pc
11		12	
	Cabinet Door (R) - 1pc		Bottom Panel - 1pc
13		14	
	Cabinet Feet - 4pcs		Sink - 1pc


Hardware List - N729P173380

<div data-bbox="97 183 196 239">A</div>  <p>ø6x35mm</p> <p>Three in one bolts (34pcs)</p>	<div data-bbox="563 183 662 239">B</div>  <p>ø14.5x12mm</p> <p>Three in one lock (34pcs)</p>	<div data-bbox="1029 183 1128 239">C</div>  <p>ø8x30mm</p> <p>Wood dowel (42pcs)</p>
<div data-bbox="97 421 196 477">D</div>  <p>ø13x1/4"x30mm</p> <p>Hex-Head bolts (4pcs)</p>	<div data-bbox="563 421 662 477">E</div>  <p>Handle (2pcs)</p>	<div data-bbox="1029 421 1128 477">F</div>  <p>Handle (1pc)</p>
<div data-bbox="97 667 196 723">G</div>  <p>ø5/32"x20mm</p> <p>Handle screw(4pcs)</p>	<div data-bbox="563 667 662 723">H</div>  <p>Damping hinge (4pcs)</p>	<div data-bbox="1029 667 1128 723">I</div>  <p>ø7xø3.5x15mm</p> <p>Flat head screw(24pcs)</p>
<div data-bbox="97 904 196 960">J</div>  <p>Laminate pad(4pcs)</p>	<div data-bbox="563 904 662 960">K</div>  <p>4mm</p> <p>Allen key(1pc)</p>	<div data-bbox="1029 904 1128 960">L</div>  <p>Anti fall hardware(1set)</p>



STEP: 1




STEP: 2






STEP: 3

B	C
	
4PCS	2PCS




STEP: 4

B	C
	
4PCS	6PCS



STEP: 5




A



5PCS

STEP: 6




B





5PCS



C



8PCS


STEP: 7

D	C
	
4PCS	8PCS




STEP: 8

A




6PCS




STEP: 9


A





8PCS






STEP: 10






B	C
	
8PCS	4PCS



STEP: 11







B	C
	
4PCS	6PCS



STEP: 12

A	B	C
		
6PCS	8PCS	6PCS




STEP: 13

E	G	H	I
			
2PCS	2PCS	4PCS	8PCS




STEP: 14


I




16PCS



Use the screws to adjust up or down Use the screws to permanent




Use the screws to adjust left or right Use the screws to adjust in or out




STEP: 15

J




4PCS




STEP: 16

S




1SET

Wall




STEP: 17

Install the sink on the cabinet with glue.
Let stand for 24 hours




*Silicone glue is not included
in the package to comply
with safety regulations in
certain shipping conditions.

STEP: 18



HINGE ADJUSTMENTS




① Sideways / Tilt adjustment

Turn the screw

clockwise to move the door further away from the side of the cabinet

anticlockwise to move the door closer to the side of the cabinet




② ④ Height adjustment

While supporting the weight of the door, turn the screws

clockwise to move the door up

anticlockwise to move the door down



③ Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw

clockwise to decrease the gap between the door and the cabinet

anticlockwise to increase the gap between the door and the cabinet

