ASSEMBLY INSTRUCTIONS

Description: Heston Accent Chair

MADISON PARK®

Important safety instructions:

- Please read carefully all instructions before assembling.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any content until assembly is completed to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any protective packaging.

Parts List

Item	Description	DRAWING	QTY
P1	Left Front Leg		1
P2	Right Front Leg		1
P3	Back Legs		2
P4	Chair		1
P5	Seat Cushion		1

Hardware List


Item	Description	DRAWING	QTY
H1	Bolts φ5/16*2-3/8"	0	8
H2	Lock Washers φ5/16"	O	8
Н3	Flat Washers φ5/16"		8
H4	Allen Wrench φ5/16"		1

DISCLAIMER:


WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR AND DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.

Assembly Procedures:


Step 1.Turn the chair upside down and lay on protective carpet, take out the legs and hardware from the bottom.



Step 2.Using bolts (H1), lock washers (H2), flat washers (H3), connect legs(P1,P2,P3) to Chair (P4). Tighten bolts (H1) with Allen Wrench (H4).



Step 3. Place the chair upright on a level surface. Put seat cushion (P5) on the chair. Assembly is complete.



ADDITIONAL NOTE ABOUT SAFETY:

BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE.

THEY SHOULD BE INSPECTED AT LEAST EVERY 3 MOTHS AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY, AND ENSURE STABILITY.