





BT-444-SD PARTS

ASSEMBLY INSTRUCTION

(1)X1 	(5)X8  M6
(2)X2 	(6)X8  6.5*18*1.5mm
(3)X2 	(7)X1  M6
(4)X8  M6*60mm	

