






Shower room mixing valve, shower room 3/4/5 way water outlet thermostated copper head, shower room thermostatic faucet




INSTALLATION INSTRUCTIONS




Square three holes trim plate - exposed parts




Round three holes trim plate - exposed parts




Square three holes trim plate - exposed parts




Round three holes trim plate - exposed parts




Square four holes trim plate - exposed parts




Round four holes trim plate - exposed parts




Square four holes trim plate - exposed parts










Round four holes trim plate - exposed parts




Square models:






Round models:




Do not turn the spindle!




Install according to the markings




Three holes trim plate




Four holes trim plate




Concealed cut-off valve



Concealed 3-way diverter



Concealed 4-way diverter



This General diagram and installation instructions are not intended for any specific model, but is presented as a general guideline for Installations!