




Components and Hardware List

<p>Bench Top</p>  <p>(A) 1 pc.</p>	<p>Legs</p>  <p>(B) 4 pcs.</p>	<p>Center Legs</p>  <p>(C) 2 pcs.</p>	
<p>M5/16" x 2" Allen Head Bolt</p>  <p>(D) 12 pcs.</p>	<p>M5/16" Spring Washer</p>  <p>(E) 12 pcs.</p>	<p>M5/16" x 19 x 2mm Flat Washer</p>  <p>(F) 12 pcs.</p>	<p>5mm Allen Wrench</p>  <p>(G) 1 pc.</p>



#59359-59459
Uph Dining Bench

Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.

To prevent possible scratches and damage, this furniture should be assembled on a soft surface such as a blanket or carpet.

Step 1: Attach the Legs (B)&(C) at the corners of the Bench Top upside down using the 2" long Head Bolts (D), Spring Washers (E) and Flat Washers (F).

Step 2: Adjust fit if necessary and tighten Bolts using the Allen Wrench (G).

WARNING
This BENCH is designed and intended for seating only. To prevent against potential injuries and structural failures, this bench should NEVER be used for other than its intended purpose.

