ASSEMBLY INSTRUCTION FOR ACME FURNITURE MODEL# DN01802 JASPER DINING TABLE

Thank you for purchasing the quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and metal hardware. Compare with all parts list to be sure all parts are present. If any part(s) are missing or damaged, please contact your local furniture dealer. For efficient and speedy service, please indicate the model number and code letter of part(s) needed.

Do not fully tighten screws until fully assembled

	COMPONENT PARTS	
DESCRIPTION	PART NAME	Q'TY (PCS)
P1	TABLE TOP	1
P2	PEDESTAL LEG	1
РЗ	MOUNTING PANEL	1

HAREWARES REQUIRED

H1		JCBC SCREW M6 x 35MM - 8 PCS
Н2	\bigcirc	SPRING WASHER - 8 PCS
HЗ	\bigcirc	FLAT WASHER - 4 PCS
H4		LEG ADJUSTABLE GLIDE - 4 PCS
Н5		WOOD DOWEL M8X30MM - 4 PCS
НG		ALLEN KEY - 1 PC

Attention:

*** Some number parts listed on the instruction sheet may not be in parts bag as they may already be assembled. Carefully check parts and packing materials prior to ordering replacements.

PAGE 1/2

