Progressive® ASSEMBLY INSTRUCTION Item No: T332-05

Description: SOFA TABLE



IMPORTANT NOTE:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Do not tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children.

End Table -

PARTS LIST				
NO.	COMPONENT			
1	TABLE TOP	1PC		
2	TABLE LEG	2PCS		
3	BOTTOM SHELF	1PC		

HARDWARE LIST				
NO.	DESCRIPTION		QTY	
А		Rotating aluminium handle Ø45*57+M4	3 PCS	
В		Bolt Ø 9*42mm	3 PCS	
С		Bolt Φ Ø 1/4" *20mmmm	3 PCS	
D		L Shaped 32*32*2 (80)	3 PCS	
Е	(A)	Bolt 1/4"(Ø 12)*15mm	6 PCS	
F		Bolt 1/4" (Ø 12)*40mm	1 PC	
G		Allen wrench M4*58mm	1 PC	
Н		Lock washer Φ 1/4"	7 PCS	
Ι		Flat washer Φ 1/4"	7 PCS	

