



PREPARATION

Before beginning the assembly of the product, make sure all parts are present. Compare the parts with the package contents list and hardware contents list. If any parts are missing or damaged, do not attempt to assemble the product. Tool required for assembly (included): Allen Key and Wrench.



Step 1: Put the leg (C) to the leg (B) same as picture . Use the wrench (D2) to tight.



Step 2: attach the legs to the table top (A) as shown on the picture. Use the Allen bolt (D1) and tighten by using the Allen key (D3) and wrench (D2).

CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when it is not in use. Dust regularly with small brush or vacuum. Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

NOTICE

Please make sure that you have all parts indicated before you begin assembly of this item.

SAFAVIEH OUTDOOR LIVING

MODEL# PAT6747

Product Dimension: 27.56"W x 27.56"D x 14.17"H

Weight capacity : 40 lbs.

Warning : Do not stand on the table

Warning : Do not torque bolts / screws



Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Table top		1x
B	Outside leg		1x
C	Inside leg		1x
D1	Allen bolt	 M6x50	4x
D2	Wrench		1x
D3	Allen Key		1x

