


## remote control operation manual



Connect the lamp with the remote:

- (1). Turn on the power supply for this lamp, that means turn your own switch on, the one on your wall.
  - (2) Hold the remote, pointing it to the lamp, then press "Setup" button in 5 seconds after step (1)
- Then, the remote is connected to the lamp.  
Key point: do (2) within 5S after you do (1)