

Revised 03/2017



Instruction Manual



IMPORTANT INFORMATION MUST READ BEFORE ASSEMBLING PRODUCT

-Follow the in formation on the warnings appearing on the upper bunk end structure and on the carton. Do not remove warning label from bed.

- Use only a mattress which is 74-75 " L x 37.5-38.5 " W x 9 " H on the upper bunk.

- Replacement Parts—Replacement parts, including additional guardrails, may be obtained from any of Walker Edison Furniture's dealers or by contacting Walker Edison Furniture online at <u>www.walkeredison.com</u>.

- Follow the information on the warnings appearing on the upper bunk end structure and on the carton. DO NOT remove warning label from bed.

- Always use the recommended size mattress or mattress support, or both, to help prevent the likelihood of entrapment or falls.

- Surface of mattress must be at least 5 in . (127 mm) below the upper edge of guardrails. Mattress must not exceed a maximum thickness of 9 inches.

- DO NOT allow children under 6 years of age to use the upper bunk.

- Periodically check and ensure that the guardrail, ladder, and other components are in their proper position, free from damage, and that all connectors are tight.

- DO NOT allow horseplay on or under the bed and prohibit jumping on the bed.

- Always use the ladder for entering and leaving the upper bunk.
- DO NOT use substitute parts. Contact the manufacturer or dealer for replacement parts.
- Use of a night light may provide added safety precaution for a child using the upper bunk.

- Always use guardrails on both long sides of the upper bunk . If the bunk bed will be placed next to the wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and wall.

- The use of water or sleep flotation mattresses is prohibited.

- STRANGULATION HAZARD – Never attach or hang items to any part of the bunk bed that are not designed for use with the bed ; for example, but not limited to, hooks, belts and jump ropes.

- Prohibit more than one person on upper bunk.
- Keep these instructions for future reference.



		Hardware	List		
A	CONTRACTOR CONT	Ø1/4"x1-1/4"	Screw	6	pcs
В		Ø5/16"x2-1/4"	Screw	8	pcs
С		Ø1/4"x5/8"	Screw	48	pcs
D	າແພນແຫຼ່ງແພນແມ	Ø1/4"x1"	Screw	6	pcs
Е	\bigcirc	Ø5/16"x18	washer	8	pcs
F	\bigcirc	Ø1/4"x16	washer	34	pcs
G				2	pcs
Н		9x14	Plastic plug	4	pcs
I		15x17	Snap plastic tab lock	44	pcs
J			Snap plastic link	21	pcs
К	\bigcirc		Washer	12	pcs
L		M5	Large wrench	1	рс
М		M4	Small wrench	1	рс
The hardware quantities listed above are required for proper assembly. Some extra hardware may also have been included.					



















Secure front guardrail (13) to crossbar (10) using large bolts (B) and large washers (E). Secure back guardrail (13) to crossbar (11) using large bolts (B), large washers (E) and, where applicable, angle brackets (G).* Tighten large bolts (B) with large wrench (L).

*OPTIONAL: Angle brackets (G) can be used to attach the bed to a wall for additional support. You must use hardware suitable for the particular wall type, which is not included as there are many different wall types. You must also mount the bed to the structure of the wall (i.e. wood studs, metal studs or cement/brick) directly. DO NOT attach the bed to the surface of the wall without anchoring into the structural framework of the wall. Please seek professional advice if you are unsure of your own ability to do this correctly. Walker Edison Furniture Company makes no representation of warranty, expressed or implied, to the strength of any structure and the wall's ability to hold your bed. You assume all responsibility and indemnify Walker Edison Furniture Company of any and all damages that may be incurred by attaching your bed to the wall.



