

ASSEMBLY INSTRUCTIONS

Item PT1837 PT1737





PARTS INVENTORY			
ID	DESCRIPTION	PIC	QTY
A1	TOP	\Diamond	1
A2	FRAME		1
A3	SHELF		1
A4	LEG		2
В	BOLT M6x40mm		18
С	LOCK WASHER		18
D	FACED WASHER		18
E	ALLEN KEY		1
F	FELT PAD		4



Top Tips before you start!

Read these instructions carefully and keep for future reference. Refer to parts inventory for guidance, and ensure you have all pieces before starting.

- 1. We recommend that, where possible, all items are assembled near to the area in which they will be placed in use to avoid moving the product unnecessarily.
- 2. When assembling, place all parts on a soft, clean, and flat surface such as a carpet to prevent any damage.
- 3. For ease and speed of assembly, we recommend that before you commence each step of the assembly, that you identify all the parts required for that step.
- 4. For larger items, please ensure that you have sufficient space and people to assemble your product safely.
- 5. During assembly, please take care not to over tighten any fittings, as this may damage the product.
- 6.When placed the front, please adjust gap and height, then tighten, two people cooperation is more easy to assemble.