

User Care Manual

Care and Cleaning

Dust regularly with a soft, lint-free cloth or a lint roller to prevent staining from dust, dirt, and other unclean particles. A damp cloth may be used minimally to clean outer surfaces. Make sure surfaces are **dry** after finishing. Keep your product away from any abrasives that may damage the finish or tear the materials. Moisture and humidity may damage and otherwise deteriorate the wood frame. Keep your product out of excessive sunlight and extreme changes in temperature to preserve the integrity of your product.

Maintenance

Check periodically if the bolts and screws have loosened over time and tighten them accordingly. Dry and remove any moisture or other liquid particle build-ups from bolts and screws to prevent rusting.

Lifting and Moving

Do not drag the product on the floor and request additional assistance. When moving the bed, it is recommended that two or more people help move the frame to the new desired location. Remove all the slats, center rail and center support legs prior to moving and replace them again after moving. Adjust and straighten the three support legs.

Other Important Instructions

This bed is designed exclusively for indoor and adult use. Children and pets should not operate the bed frame without the use of adult supervision. Do not sit on the headboard or footboard of a bed or the arms of a daybed as this may cause damage to the base of the wood frame.

