




1.Remove the rubber washer, metal 2.Screw and hand tighten the hot and washer and locking nut from the faucel.




cold flexible hoses to the faucet. Do not use a wrench to tighten hoses as this may damage the hose and/or the hose threads.





3.Install faucet through center hole. 4.Re-install the rubber washer followed by the metal washer and lock—nut.Hand tighten then tighten further using a screw driver to tighten lock nut screws.



5. Attach flexible hose to water supply.

