



veradek ——— outdoor


# privacy screen set instructions




# parts and components




Although the arrow pattern is shown, these assembly instructions apply to all panel privacy screen sets.



not included





wrench





a soft working surface  
for assembling your items


# step 1




# step 2





# step 3





# step 4




## step 5



## step 6



# complete



Our screens need to be firmly secured to a surface, whether that be a wall or floor, to make sure they don't knock over on a windy day. If you're unsure of how to properly secure your screens, we suggest getting in touch with your local contractor.



## hello, *sunshine!*

That was easy – time to enjoy  
your outside space.

meet you  
outside

veradek ——— outdoor