
Universal Steel Hammock Stand



Components

Base 2 pieces Crossbar 1 piece Hammock Frame Bar 2 pieces Hook, Washer & Wingnut 2 pieces Bolt 5 pieces

Camping Carry Bag

Assembly Instructions

- 1. Place all the pieces on the floor
- 2. Connect the crossbar with the bases, screw the bolts tightly into place
- 3. Connect the hammock frame bar with the bases, screw the bolts tightly into place
- 4. Put the hook and washer in the appropriate hole to suit hammock size
- 5. Screw the wingnut to fix the hook
- 6. Hang the hammock according to the photograph (right)- hammock should only have a slight curve when first fitted to accommodate weight. Adjust as cotton stretches.
- 7. WARNING. Do not leave children unattended while on the hammock.
 Not to be used as a swing. Always enter your hammock in the middle. Do
 not sit past the base legs. Regularly check hook and wingnuts are tight.
- 8. Inspect the hammock and frame regularly for deterioration or damage.

 Do not use if worn or damaged

