



ASSEMBLY INSTRUCTION

SUNPAN








Sunpan Product Name: **CASSIUS SWIVEL DINING ARMCHAIR**

Please visit our website **www.sunpan.com** for more great products




For assembly questions please call **1-800-787-1019 (or +1-416-736-0094)** outside North America or email to **info@sunpan.com**

PARTS LIST

Before you begin, please layout all parts and ensure you have the correct count.

PARTS	DESCRIPTION	QUANTITY	ILLUSTRATION
A	Seat	1	
B	Base	1	
C	Washers	4	
D	Screws (Ø6*20mm)	4	
E	Allen Key	2	
F	Spanner	1	
G	Base including wood panel	1	

ASSEMBLY INSTRUCTIONS

STEPS	DESCRIPTION	ILLUSTRATION
1	Take out Base including wood panel (G) from the box. Use Allen Key (E) to hold the screws on top, use Spanner (F) to loose the hex nuts.	
2	Place Base (B) onto bottom of Seat (A). Tighten the Washer (C) and Screw (D) by using the Allen Key (E).	
2	Assembly completed.	

ASSEMBLY TIPS:

Please check parts and hardware before assembling. Follow each instruction step by step.

Place a protective pad or piece of cardboard on the floor while assembling your item on top of it.

Remove all parts from the carton and separate them into part numbers/groups as indicated on the part list.

Please follow instructions in the sequence as numbered to assure fast/easy assembly.

WARNING:

Don't attempt to repair or modify parts that are broken or defective - if you find a broken part please contact us for replacement.

Keep all hardware parts out of the reach of children.

FURNITURE CARE:

Following these few basic steps will help to ensure that you enjoy your furniture for a long time:

Do not expose your furniture to direct sunlight, dampness or any heat, like a hot cup of coffee or tea. Always use a coaster.

Excessive exposure to sunlight may cause fading.

Excessive temperature and humidity or cold may cause cracking or splitting.

Dust with a clean, damp, lint free cloth.

Use a damp cloth with water or mild detergent to clean all surfaces - do not use chemicals or paint thinner which will fade the surface.

Place a piece of felt or a pad under the legs of your furniture to avoid scratching the floor.