

Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion within the 1-year warranty period. Proof of purchase, with the date of purchase as well as photos of the merchandise defect, must be provided. Photos are used to determine the cause of defects and for future quality control. Register your warranty at <a href="https://tiny.cc/SunnydazeWarranty">https://tiny.cc/SunnydazeWarranty</a>

If you have any questions, comments or concerns, feel free to contact us by phone at **833-982-1977**, by email: <u>customerservice@sunnydazedecor.com</u>, or via our contact us page at <u>https://tiny.cc/SunnydazeContact</u>

# General Use & Care Manual: Brazilian Hammock

## HAMMOCK CARE

Under normal use, your hammock will last for years. It is important to follow these basic tips to prolong the life of your hammock:

• LOCATION: A shady spot is best for hanging your hammock. The less direct sunlight the hammock is exposed to, the longer the life of the fabric and ropes will be.

• **STORE IT:** Keep your hammock indoors during bad weather, the winter months and when it will not be used for an extended period of time. Limiting your hammock's exposure to the elements will prolong its lifespan. Make sure it is completely dry before storing.

• **PROTECT IT:** Do not allow children or pets to play in the hammock. Excessive swinging or rough play may cause injury or wear the hammock out prematurely.

### **GETTING IN**

Turn your back to the hammock. Reach behind your body and lift the far side. Place your other hand on the near edge and lift yourself into the hammock similar to how you would sit in a chair. Lift your legs into the hammock and position yourself however feels most comfortable.

#### CLEANING

X DO NOT use bleach or fabric softeners.

👿 🗕 Do not tumble dry - lay flat to dry.

Tie rope ends at equal intervals with pieces of cord so there is less risk of tangled ropes.

**Hand-wash** with warm water, soap or mild detergent, and a soft-bristled scrub brush. Rinse thoroughly, ensuring all soap residue has been removed. Air-dry only, laying the hammock on a flat surface to prevent the ropes from stretching.

**Machine wash** on the gentle/delicate cycle, using a mesh net laundry washing bag and mild detergent. Before placing your hammock in the laundry washing bag, tie the ends of the hammock together to prevent tangling. Air-dry only, laying the hammock on a flat surface to prevent the ropes from stretching.

Never fold the hammock when wet or store it in a damp place.

# 🚹 SAFETY STATEMENTS & WARNINGS <u>/</u>

#### Safe Use of Your Hammock

- Before each use, inspect your hammock for wear or weakness.
- Take your time getting into and out of your hammock. Any hammock may tip if your weight isn't centered.
- Excessive swinging and other rough play may result in injuries and may wear out your hammock prematurely.
- Small children should not play unsupervised in your hammock.
- Pets should not be allowed into hammocks as it may result in injuries or damage the product.
- Do not exceed the recommended weight capacity of the hammock.