

# Assembly Instructions

## Lift Recliner

Your recliner comes packaged in one box. Carefully remove all the components from the packaging and set aside for assembly.

Package Contents.

Ⓐ 1 x Seat



Ⓑ 1 x Seat Back



Ⓒ 1 x Power Kit




Ⓓ 4 x Legs




**CAUTION:**  
Tighten all components securely before use. Failure to do so may result in personal injury.

DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.


Step 1




Step 2




Step 3



Reclined



Lifted



Style may vary.

Care for your furniture. Periodically tighten all legs. Vacuum cushions regularly.

Do not return product to retail store.

Call Customer Support: 866-238-0531

Mon-Fri 8:00am - 4:30pm CST

customerservice@furniturequestions.com

Update:08.10.2017

Parts - 1 Year Warranty: The furniture is warranted against defects in workmanship and materials. Items covered would be seam slippage, frame structural integrity, fit and finish of parts. Items not covered would be product abused by the user, normal wear and tear, stains or discoloration due to use, damage in any transportation. Softening of foam is considered normal wear and tear and is not covered by warranty. Warranty is for PARTS ONLY and does not include transportation and labor costs associated with any warranty claim.