

JONATHAN ADLER LIGHTING

Puzzle Table Lamp (US version) Assembly Instruction

Safety Instruction:

- For safety purposes, this lamp is equipped with a polarized plug (one blade is wider than the other). Only plug the lamp into an extension cord if it can be fully inserted into the cord's socket. Never alter the plug in any way.
- These instructions are provided for your safety, it is important that they are read carefully and completely before assembling.
- This fixture has been rated for up to (1) E26 100-watt maximum TYPE A standard bulb (not included).
- SAVE THESE INSTRUCTIONS.

WARNING:

- To reduce the risk of fire, electrical shock or personal injury, always turn off light fixture and allow it to cool prior to replacing light bulb.
- Do not touch bulb when fixture is turned on and do not look directly at lit bulb.
- Keep flammable materials away from lit bulb.

Pre-assembly:

- Remove all parts and hardware from box along with any plastic protective packaging.
- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware

Parts enclosed:

- (1) Finial (A)
- (1) Rubber Washer (B)
- (1) Lamp Shade (C) – Separately Packed
- (1) Harp (D)
- (2) Harp Caps (E)
- (1) Socket (F)
- (1) Saddle (G)
- (1) Lamp Base (H)

To Assemble:

1. Press the sides of Harp (D) in order to slide it into slots of Saddle (G).
2. Lower the Harp Caps (E) onto the Saddle (G) to fix in place.
3. Unscrew the Finial (A) from the Harp (D) and place lamp Shade (C) on the Harp (D), and screw the Finial (A) with Rubber Washer (B) back onto the Harp (D).
4. Insert (1) E26 100-Watt Type A bulb (not included) into the socket.
5. Plug into proper electrical outlet and test the lamp.
6. Assembly is completed.

Care Instruction:

- Wipe clean using a soft, dry cloth or static duster.
- Always avoid the use of harsh chemicals and abrasives to clean fixture as they may damage the finish.

