









MADISON PARK® PARKER DESK

Assembly instructions:

PARTS LIST

No.	DESCRIPTION	IMAGE	QTY
P1	TOP		1
P2	LEFT LEG		1
P3	RIGHT LEG		1
P4	BASE		1

HARDWARE LIST

No.	DESCRIPTION	IMAGE	QTY
H1	BOLT (ø1/4" x 38mm)		12
H2	SPRING WASHER (ø1/4" x 11mm)		12
H3	FLAT WASHER (ø1/4" x 16mm)		12
H4	ALLEN KEY (M4 x 60mm)		1


**NOTE:** PO # is located underneath/ at the back side of each item. Please be prepared to provide this # should any claim be necessary.

**CAUTION:** Item is heavy. Assembly should be performed by two people.


DISCLAIMER:

When properly assembled, this item is safe for intended use. Seller is not liable for any damages resulting from item being improperly assembled after purchase.

1




2




PLS, DON'T TIGHTEN BOLTS UNTIL LAST STEP.

3

PRESS THESE MECHANISMS TO OPEN DRAWER DROP FACE PANEL



ASSEMBLY COMPLETED



ADDITIONAL NOTE ABOUT SAFETY:  
BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE.  
THEY SHOULD BE INSPECTED AT LEAST EVERY 3 MONTHS AND RE-TIGHTENED AS NEEDED TO PREVENT DAMAGE OR INJURY. AND ENSURE STABILITY.  
Thank you for your purchase