Visional/HINES)\$\$\\$18\C\0\X\8\138\p3+34-8\2\du_p 2821/10\9 818\t |FF 52045, Admini

1 of 2

ReleasedDate:2017-08-14

For Style 1269P24 Assembly Instruction Sheet #IS- 1269P24


udiver, pliem, wire cuttern, wire strippern, electrical tape, safety glasse


the Required: Plathed corenthier, Philips screediver, plies, wire culture, who elippers, electrical laps, safety glasses. It Beares: (24)E12 MAX 60W (hat Include). It Beares: (24)E12 MAX 60W (hat Include). It Beares: (24)E12 MAX 60W (hat Include). Include the second description of the second description

Warnings and Cautions

We strongly recommend that a licensed, pro Turn off electricity at circuit breaker or main fluse box before installation. Consult a licensed electricism if in doubt. These instructions are provided for your safety. It is very important you read them completely before installing the sty. It is very important you reed them completely before installing the fixture (feational electricism perform the installation.


Disconnect fixture from power source before replacing bufbs. Make sure bufbs are given sufficient time to cool before removal






Wire Length Adjustment


1,The locking pin is located at the metal canopy



2, Locking pin



3,Long press the locking pin into the ceiling canopy,which will release the cable locking mechanism.



4,while holding the pin in place,simply pull down/push up the cable to adjust the height.

